

This manual is an add-on for the **Fire container manual**, and describes **installation and usage of swoop risers.**

Swoop risers have 2 differences, the front riser handle and the line stow point.

**Riser handle:**



It's critical to install the risers as described in the photo. You need a reserve soft link because a main softlink would be too short.

You also have to keep in mind that attaching the link to the handle without the riser can lead to canopy detaching and a malfunction. Attaching the link to the riser without the handle can lead to handle breaking.

**SWS Fire Swoop Risers Owner's Manual**  
**SWS Fire Свуп СК Руководство пользователя**

**Line stowing:**

Rear riser has 2 guide rings, with line going through 1 of them, the top.



For stowing, fold the line in the stow loop point in half, insert into bottom ring.



Put the pin into the stow loop, under the ring, than above it.



**SWS Fire Swoop Risers Owner's Manual**  
**SWS Fire Свуп СК Руководство пользователя**

Stow pin into the pocket above the bottom ring and the upper and lower tabs of the brake handle in pockets accordingly.



Place the excessive line in the pocket on the rear side of the riser.



**Blue skies and have a good one.**