



2. SWS will send a retrofit set including new reserve freebag with DRD pocket, DRD handles, trigger pocket and line pocket set to the specified service center to be installed.



3. A qualified master rigger (or equivalent) will install the pockets on the DRD flap at the service-center. The work requires: medium duty lockstitch sewing machine, nylon thread number 40 (E-thread or number 69 in American nomenclature).



3.1. Attach trigger pocket on the DRD flap. The center of the pocket must line up with the center of the grommet and the top edge of the pocket (with horizontal stitching) should line up with grommet inside edge. The pocket is sewn with 1 row of stitching on the 2 vertical sides of the pocket. The stitch should reach over the edge of the pocket on to the DRD flap. (as seen in the photo below)



3.2. Position the elastic line pocket in the middle of the DRD flap, one centimeter from the top edge and attach it by sewing two rows of stitches on the top of the stitches of the binding tape.



3.3. Check correctness of the assembly. Document the alteration in the parachute documents: «DRD modification performed according to SWS bulletin №201312».

